λ puture°

MC プロダクト マニュアル

日本語

Foreward

Thank you for purchasing the Aputure MC.

Instructions

- Please read this product manual carefully.
- Keep this product manual and always include it when passing the product onto third parties.



WARNING: Do not place the product near any corrosive hemicals. Corrosion may cause the product to malfunction.

- Only use a microfiber or dry cloth to clean the product.
- Be careful to not damage the light by dropping it or otherwise introducing physical shock.
- Do not leave the product in excessive heat, high temperatures can cause the product to malfunction.
- Please have the product checked by the authorized service or agent if your product has some problems. Please note that this warranty does not apply to repair arising out of the malfunction of unauthorized disassembly, although you may request such repairs on a chargeable basis.
- Use of original Aputure cable accessories is recommended. Please note that this warranty does not apply to repairs arising out of the malfunction of non-original Aputure accessories, although you may request such repairs on a chargeable basis.
- The product is certificated by RoHS and CE. Please operate the product in full compliance with the operation standards. Please note that this warranty does not apply to repair arising from malfunction, although you may request such repairs on a chargeable basis.
- The instructions and information in this manual are based on thorough. controlled company testing procedures. Further notice will not be given if the design and specifications change.

Intended Use

Intended use of the Aputure MC includes:

- The user has read the instructions of this manual.
- The user is using the products within the operating conditions and
- a limitations described in this product manual.
 - "Improper use" means using the products other than as described in these instructions or under operating conditions which differ from those described herein.

アイテムリスト

パッケージ アイテムリスト:



MC (1 pc)



Adhesive Mounting Tape (2 pairs)



USB Type-C Charging Cable (1 pc)




Silicone Rubber Diffuser (1 pc)



Carrying Case (1 pc)

プロダクト




- ① 有機ELディスプレイ
- ② コントロールウィール
- ③ パワースイッチ
- ④ USB Type-C 充電ポート
- ⑤ マグネット
- ⑥ 1/4"-20 ネジ穴

操作方法

1.充電

1). Type C 充電


端末が充電されている時は、バッテリーの残量アイコンが点滅します。 充電が完了したらバッテリー残量アイコンがフルの表示になります。



- *5V/2Aのモバイルバッテリー充電に対応
- *USB-C PD 急速充電対応
- * バッテリー残量が少ないとアイコンが点滅します

2). ワイヤレス充電


MCはQiのワイヤレス充電に対応しています。 5W Qi規格対応のワイヤレス充電器で充電出来ます。



* MCを充電する際は、ライトを消してから充電してください。 点灯しながらの充電は、充電スピードが遅くなります。

2. 電源 ON/OFF

電源はスイッチの操作でONとOFFに出来ます



3.CCT モード

システムメニューを開くには、コントロールウィールを2秒以上押します。 コントロールウィールを同して【CCT】を選択します。

CCTモードでは、コントロールウィールを回して色温度を3200ー6500Kに変更できます。 設定の切り替えは、コントロールウィールを押して変更出来ます。

【INT】は、0-100%に調節可能。



5600K 100% 🛔

*Sidus Link appを使用する事で、より細かな操作と設定が出来ます。

4.HSI T-K

システムメニューを開くには、コントロールウィールを2秒以上押します。

コントロールウィールを回して【HSI】を選択します。

HSIモードでは、コントロールウィールを回して【HUE·SAT·INT】(色彩・彩度・光量)の設定を変えれます。

設定の選択は、コントロールウィールを押して出来ます。

【HUE】は、0-360°に調節可能。

【SAT】は、0-100%に調節可能。

【INT】は、0-100%に調節可能。





SAT 100% ▶ 🖺

INT 100% ▶ 🖺


(1) パパラッチ


システムメニューを開くには、コントロールウィールを2秒以上押します。 コントロールウィールを回して【FX】を選択します。


FXモードでは、コントロールウィールを回して【Paparazzi・Fireworks・Faulty Bulb・ TV·Lightning·Party·Pulsing·Cop car·Fire】に設定を変えれます。

設定の選択は、コントロールウィールを押して出来ます。

各FXは、光量設定を調節できます。設定するにはコントロールウィールを押して【INT】 設定で変更します。【INT】は、0-100%に調節可能。










6. Bluetooth モード

システムメニューを開くには、コントロールウィールを2秒以上押します。 コントロールウィールを回して【BT】を選択します。


BT Resetモードでは、コントロールウィールを回して【YES】を選択すれば Bluetoothのペアリングを行えます。Sidus Linkに接続する際に使用します。 【NO】を選択すればシステムメニューへ戻ります。

設定の選択は、コントロールウィールを押して出来ます。

ГХ **ВТ** ССТ *****




7.シリコンデフューザーの付け方




8.マジックテープの使い方





9.マグネットの使い方





^{*}MCライトは80°以上の場所では使用しないで下さい。 故障の原因になります。

10. Sidus Link APPの使い方

スマートフォンをと通してのライト操作が可能になる Sidus Link appはApp store又はGoogle playから ダウンロード出来ます。

アプリに関しての情報は sidus.link/app/helpのサイトから、より詳しく調べる事が出来ます。 Sidus LinkはiOSとAndoroidに対応しています。

7 '0 0



スペック

巴温度			3200-6500K				
CRI			96+				
TLCI			97+				
距離	0.3M	0.5	M	1M			
光量(ルクス)	1100 lux	400 l	ux	100 lux			
バッテリー			リチウムポリマー電池 (3.7V 2600mAh)				
消費電力			5W				
本体温度			0 °C to 45 °C				
バッテリー駆動時間		最大出力		最低出力			
		>2時間		>15時間			
充電時間		~1.5 時間 (USB PD)					
		~2時間 (USB DC 5V/2A)					
			~3.5時間 (ワイヤレス充電)				
本体寸法	93x61x17mm/3.66x2.40x0.67in						
	CRI TLCI 距離 光量(ルクス) ベッテリー 消費電力 本体温度 ・リー駆動時間 充電時間	CRI TLCI 距離 0.3M 光量(ルクス) 1100 lux パッテリー リチャ 消費電力 (3: 本体温度 0 ニリー駆動時間 最大出 シ2時間 ~1.5 財 売電時間 ~2.5時間 ~3.5 財 ~3.5 財 ~3.5 財 ~3.5 財 ~3.5 財 ~3.5 財 ~3.5 財 ~3.5 財	CRI 96+ TLCI 97- 直離 0.3M 0.5 光量(ルクス) 1100 lux 400 l ドッテリー リチウムポリー(3.7V 260 5W 消費電力 5W 5W 本体温度 0 °C to 4: 最大出力 シ2時間 ~1.5時間(U 充電時間 ~2.9時間(U ~3.5時間(T) ~3.5時間(T)	CRI 96+ TLCI 97+ B重難 0.3M 0.5M 光量(ルクス) 1100 lux 400 lux パッテリー リチウムポリマー(3.7V 2600mAl 3V 消費電力 5W 5W 本体温度 0°C to 45°C 2大出力 最大出力 二リー駆動時間 大出力 2ショ時間 15時間(USB PC 二・2・時間 (USB DC ~3.5 時間(USB DC ~3.5 時間(USB DC (V3 DC ~3.5 時間(USB DC			

^{*}光量(ルクス)は、各MCライトで数値が多少異なる可能性があります。

^puture® | GUARANTEE CARD

Franchiser Seal	Buyer Add	Buyer Phone	Buyer Name	Purchase Date	Item Name	Serial No.

^puture

Aputure Imaging Industries Co.,Ltd.

Inspection: Qualified

Add: F/3, Building 21, Longjun Industrial Estate, Heping West Road, Shenzhen, Guangdon,

Service Warranty (EN)

date of purchase. For more details of warranty visit www.aputure.com from defects in material and workmanship for a period of one (1) year after the Aputure Imaging Industries Co., Ltd. warrants the original consumer purchases

Important

date, serial No. of the product. This information is required for warranty Keep your original sales receipt. Be sure the dealer has written on it the

This warranty does not cover

- Damage that is the result of misuse, abuse, accident (including but equipment for which it was not intended. maladjusted associated equipment, or the use of the product with not limited to damage by water), faulty connection, defective or
- date of purchase. Cosmetic damage caused by improper handling is Cosmetic defects that appear more than thirty (30) days after the
- Damage that occurs while the product is being shipped to whoever will service it.

This warranty is void if:

The product identification or serial No. label is removed or defaced in

or an authorized Aputure dealer or service agency. The product is serviced or repaired by any one other than Aputure

Aputure Imaging Industries Co., Ltd

E-MAIL: cs@aputure.com Add: F/3, Building 21, Longjun industrial estate HePing West Road, Shenzhen, Guangdong

Sales Contact: (86)0755-83285569-613